

RHINO-STOP® Truck-Guard Inspection Form

Inspection Date	
Client	
Project Reference	
Name of Inspector	
Company	

No	The concrete footing is reinforced and a minimum 150mm thick, 32Mpa strength.
No	The concrete footing is free from defects and cracks.
No	The rear of base plate does not extend beyond slab edge.
No	Anchor holes have been drilled to a minimum depth of 105mm ± 5mm using a 20mm masonry drill bit.
No	Anchor holes are thoroughly cleaned in accordance with procedure set out by the bolt manufacturer.
No	Post spacing does not exceed 2.0m.
No	Each installation is supported by a minimum five (5) posts when the barrier is specified as Type G loading.
No	Each post is secured with two (2) M20 FBN II galvanised anchors with a minimum embedment depth of 100mm.
No	Top of anchor bolts should not be cut - this is so compliant embedment depth can be verified after installation.
No	Each anchor is tightened to 200Nm.
No	A top and lower w-beam guardrail panel is secured to each post using a M16 bolt & nut.
No	Each w-beam guardrail is spliced together using eight (8) M16 x 32mm mushroom head bolt & nuts.
No	Any cuts to the galvanised components have been treated with a zinc rich paint.
No	The area around the system is clean and free from debris.
	No No No No No No No No No No

Applies to RHINO-STOP® Truck-Guard Type 2, 3 & 5 only

Yes	No	Each handrail extension is secured to the post with one (1) M16 bolt & nut.
Yes	No	The handrail pipe passes through the loop of each handrail extension and is secured with one (1) tek screw.
Yes	No	Pipe sections are joined using sleeve connectors.
Yes	No	Pipe sections are terminated with end caps.



RHINO-STOP® Truck-Guard Inspection Form

Applies to RHINO-STOP® Truck-Guard Type 4 & 5 only

	Yes	No	Starting at the edge, the mesh panels are secured to the upper and lower corrugation of the w-beam rails with self-drilling screws & mesh washers, spaced at maximum 500mm centres.
	Yes	No	Starting at the edge, the mesh panels are secured to the top and bottom support angles with M8 cup head bolts, nuts & mesh washers, spaced at maximum 500mm centres.
	Yes	No	At the end of the system, the edge of the mesh panel is shielded with an offcut of equal angle and secured as shown on Safe Direction drawings.
	Yes	No	There are no gaps in the system greater than 120mm.

Applies to RHINO-STOP® Truck-Guard Type 5 only

Yes No	C	The top support angle and mesh panel is secured to the handrail extension with two (2) M8 cup head bolts, nuts & mesh washers.
--------	---	--

The above checklist applies to the installation of RHINO-STOP® Truck-Guard using Fischer FBN II galvanised anchors.

Comments/Notes

