



# RHINO-STOP® Inspection Form

<b>Inspection Date</b>	
<b>Client</b>	
<b>Project Reference</b>	
<b>Name of Inspector</b>	
<b>Company</b>	

Yes	No	The concrete footing is reinforced and a minimum 150mm thick, 32Mpa strength.
Yes	No	The concrete footing is free from defects and cracks.
Yes	No	The rear of base plate should not extend beyond the slab edge.
Yes	No	Anchor holes have been drilled using a 20mm masonry drill bit to depths as shown on Safe Direction drawings.
Yes	No	Anchor holes are thoroughly cleaned in accordance with procedure set out by the bolt manufacturer.
Yes	No	Post spacing does not exceed 2.0m.
Yes	No	Each installation is supported by a minimum three (3) posts.
Yes	No	Each post is secured with one (1) M20 FBN II galvanised anchor to depths as shown on Safe Direction drawings.
Yes	No	Top of anchor bolts should not be cut – this is so compliant embedment depth can be verified after installation.
Yes	No	Each anchor is tightened to 200Nm.
Yes	No	The w-beam guardrail is secured to each post using one (1) M16 bolt & nut.
Yes	No	Each w-beam guardrail is spliced together using eight (8) M16 x 32mm mushroom head bolt & nuts.
Yes	No	Any cuts to the galvanised components have been treated with a zinc rich paint.
Yes	No	The area around the system is clean and free from debris.

**Applies to RHINO-STOP® Type 2, 3, 4, 5 & 6 only**

Yes	No	Each handrail extension is secured to the post with two (2) M16 bolts & nuts.
Yes	No	The handrail pipe passes through the loop of each handrail extension and is secured with one (1) tek screw.
Yes	No	Pipe sections are joined using sleeve connectors.
Yes	No	Pipe sections are terminated with end caps.



# RHINO-STOP® Inspection Form

**Applies to RHINO-STOP® Type 4 & 6 only**

Yes	No	The bottom support angle and mesh panel is secured to the base of each post with two (2) M8 cup head bolts, nuts & mesh washers.
Yes	No	The top support angle and mesh panel is secured to the handrail extension with two (2) M8 cup head bolts, nuts & mesh washers.
Yes	No	Joins in the mesh support angle (top & bottom) are positioned at a post/handrail extension location.
Yes	No	Starting at the edge, the mesh panels are secured to the top and bottom support angles with M8 cup head bolts, nuts & mesh washers, spaced at maximum 500mm centres.
Yes	No	Starting at the edge, the mesh panels are secured to the upper and lower corrugation of the w-beam rails with self-drilling screws & mesh washers, spaced at maximum 500mm centres.
Yes	No	The mesh panels are joined together with 2 off galvanised tie wires, 3mm diameter.
Yes	No	At the end of the system, the edge of the mesh panel is shielded with an offcut of equal angle and secured as shown on Safe Direction drawings.
Yes	No	There are no gaps in the system greater than 120mm.

The above checklist applies to the installation of RHINO-STOP® using Fischer FBN II galvanised anchors (supplied by Safe Direction).

Comments/Notes

